

On-Grid SUN2000-
10KTL-M0
3 Phase

www.PriceCity.com.PK

Fault Code/Error Code with Reason

Alarm Code	Alarm Detail	Alarm Code	Alarm Detail
2001	High String Input Voltage	2035	Grid Voltage Imbalance
2003	DC arc fault	2036	Grid Over-frequency
2011	String Reverse Connection	2037	Grid Under-frequency
2012	String Current Back-feed	2038	Unstable Grid Frequency
2014	High Input String Voltage to Ground	2039	Output Over-current
2015	PV String Loss	2040	Output DC Component Over high
2021	Self-check failure AFCI	2051	Abnormal Residual Current
2031	Phase Wire Short-Circuited to PE	2061	Grounding Abnormal
2032	Grid Loss	2062	Low Insulation Resistance
2033	Under-voltage Grid	2063	Cabinet Over-temperature
2034	Over-voltage Grid	2064	Fault in Device

On-Grid SUN2000-
10KTL-M0
3 Phase

www.PriceCity.com.PK

Alarm Code	Alarm Detail	Alarm Code	Alarm Detail
2065	Software Version Unmatched or upgrade Failed	2087	Internal Fan Abnormal
2066	License Expired	2088	Abnormal DC protection unit
2067	Faulty Power Collector	2093	Abnormal DC Switches
2085	Built-in PID operation abnormal	2038	Unstable Grid Frequency
2086	External Fan Abnormal	61440	Faulty Monitoring Unit

Scan QR Code



FOR FULL SPECIFICATIONS

 www.PriceCity.com.PK